

**BAVARIAN AUTOSPORT**

# Audio Upgrade Kit Installation Instructions

**PRE-INSTALLATION:** Make sure the radio and ignition switches are both in the OFF position.

**NOTE:** The Bavarian Autosport Audio Upgrade Kit comes pre-set for optimum operation under most conditions. It is recommended that these settings be left unchanged.

**PART NUMBER:**

INF SWK E34L

**APPLICATION:**

5 series 3/93 thru 96

**PROCEDURE:**

*For best results, please read these instructions step by step before starting installation.*

1. Your BMW's amplifier is located in the left rear corner (near driver's-side taillight) of the trunk behind the trim panel. To access, fold back the corner of the floor mat, remove the two plastic locking tabs and peel back the side trim panel by pulling the top rear corner down and out toward the middle of the trunk.
2. The factory amplifier is attached to the back of a gold-toned mounting bracket. This bracket is secured to the inner trunk panel by four Phillips head screws. Remove the two upper screws and loosen the two lower screws. Slide the amplifier/bracket assembly toward the rear of the car and push the lower screw heads through the holes in the panel. Continue to move the assembly to the rear until you can tilt the top down and out toward the center of the trunk. Gently lay the assembly on the trunk floor.
3. On the end of the factory amplifier that was pointing downward in the installed position you will find two plugs. Squeeze the tabs on the larger plug (with 12 wires) and disconnect it from the amplifier socket. Verify that the plug on the wiring harness of the Audio Upgrade Kit has the same number of pins as the BMW amplifier plug. (If the pin count does not match, call 800-535-2002 for further assistance). Connect the factory amplifier plug to its mate on the subwoofer harness. Plug the other end of the harness into the BMW factory amplifier socket.
4. Guide the factory amplifier/bracket assembly back into position on the inner trunk panel. Carefully position the new wiring harness to prevent pinching or damaging it. Replace and tighten the Phillips head screws holding the amplifier bracket to the inner panel.
5. Direct the wiring harness out of the amplifier compartment around the side of the trim panel and push the trim panel back into position. Replace the two plastic locking plugs. Fold the floor mat back into position.
6. Close the trunk and enjoy!

**CAUTION:** Before participating in a driver's school, autocross or other activity that involves spirited driving, disconnect the Audio Upgrade Kit and remove it from the trunk.

**INSTALLING & USING THE OPTIONAL REMOTE CONTROL**

The optional remote control knob allows you to adjust the subwoofer to suit the type of music being played or to compensate for various conditions (heavy traffic, road noise, etc.). The remote control plugs into the back of the Infinity amplifier. It has a long cord that you can "snake" through the passenger area, up to the dash and mount wherever you prefer. To operate the remote control, simply turn the knob to the desired setting. If you do not have the remote control and would like to add it (part# BASSLINK REMOTE), call your sales rep or visit [www.bavauto.com](http://www.bavauto.com).



Call Toll Free: **1.800.535.2002**

275 Constitution Avenue, Portsmouth, NH 03801 • 603.427.2002 • Fax 800.507.2002 • [www.bavauto.com](http://www.bavauto.com)