

BAVARIAN AUTOSPORT

Audio Upgrade Kit Installation Instructions

PRE-INSTALLATION: Make sure the radio and ignition switches are both in the OFF position.

NOTE: The Bavarian Autosport Audio Upgrade Kit comes pre-set for optimum operation under most conditions. It is recommended that these settings be left unchanged.

PART NUMBER:

INF SWK E36C

APPLICATION:

3 series convertible 93 thru 99

PROCEDURE:

For best results, please read these instructions step by step before starting installation.

1. If you have a factory CD changer in your trunk, you will need to remove it from its bin. Locate the two locking tabs on the under side of the changer, release them and slide the CD changer out.
2. Your BMW's amplifier is located behind the rear seat backrest.
For convertibles with rear seat headrests: Raise the headrest up as far as possible. Press lightly against the guides in a forward and backward direction and pull out in an upward direction. Proceed to step 3.
For convertibles without rear seat headrests: Proceed to step 3.
3. Pull the center armrest forward, unclip the fastener and remove.
4. Unclip the rear seat cushion on the left and right and lift out.
5. Unclip the backrest on the top left and right. Pull down and forward to remove. [NOTE: when replacing the backrest, make sure the left and right tongues on the bottom of the backrest are properly seated in their holders.]
6. To access your BMW's amplifier, pull open the rubbery trim panels in the back wall. Unscrew the three fasteners holding the amplifier in place and tilt the amplifier forward. On one end of the factory amplifier you will see two plugs. Find the larger black plug (with 12 wires going into it). Squeeze the tabs on this plug and disconnect it from the amplifier socket. Verify that the plugs on the wiring harness of the Audio Upgrade Kit have the same number of pins as the plug you have just disconnected. (If the pin count does not match, call 800-535-2002 for further assistance). Connect the factory amplifier plug to its mate on the subwoofer harness. Plug the other 12-pin plug on the subwoofer harness into the BMW factory amplifier socket.
7. Following the path used by the CD changer wiring, pass the free end of the subwoofer harness through to the trunk. In the trunk, connect the subwoofer harness to the pigtail coming out of the subwoofer box.
8. Test your new sound system to make sure all connections are tight. When satisfied that the Audio Upgrade Kit is working, replace the amplifier trim panels, rear seat backrest, rear seat cushion, armrest, headrests (if applicable) and CD changer (if applicable). Close the trunk and enjoy!

CAUTION: Before participating in a driver's school, autocross or other activity that involves spirited driving, disconnect the Audio Upgrade Kit and remove it from the trunk.

INSTALLING & USING THE OPTIONAL REMOTE CONTROL

The optional remote control knob allows you to adjust the subwoofer to suit the type of music being played or to compensate for various conditions (heavy traffic, road noise, etc.). The remote control plugs into the back of the Infinity amplifier. It has a long cord that you can "snake" through the passenger area, up to the dash and mount wherever you prefer. To operate the remote control, simply turn the knob to the desired setting. If you do not have the remote control and would like to add it (part# BASSLINK REMOTE), call your sales rep or visit www.bavauto.com.



Call Toll Free: **1.800.535.2002**

275 Constitution Avenue, Portsmouth, NH 03801 • 603.427.2002 • Fax 800.507.2002 • www.bavauto.com