

BAVARIAN AUTOSPORT

# Burlwood E-Brake Handle Installation Instructions

*NOTE: In some instances, the original E-Brake handle will be damaged or destroyed in the process of removing it. If this is undesired, proceed with care and stop short of any process that would damage the handle. You are welcome to return the wood handle if this is the case.*

**PART NUMBERS:**

GSBE 3ER - 3 Series 92 on, Z3

GSBE 5ER - 5 Series 89 on, 7 Series 88 thru 94

**PROCEDURE:**

1. Release the E-Brake. Unscrew the release button and remove it.
2. The original E-Brake handle is to be pulled off. there are no locking tabs, screw threads or any other mechanical means of securing the handle to the lever. However, on the newer models, the fit is very tight and the handle may be glued on. If pulling and twisting on the handle will not remove it, the handle will have to be knocked off from behind using a wood block and a hammer OR cut off.
3. Once the original handle is removed, clean up the lever and slide the new Bavarian Autosport Burlwood knob onto the lever. Gently twist and pull the knob into position so that it is secure. Replace the screw-on release button.

