



**BAVARIAN AUTOSPORT**

# Clear or Smoke Parking Lights/Headlight Covers Installation Instructions

**SAFETY WARNING:** Be sure the ignition switch and light switch are in the **OFF** position before removing or attaching any electrical connectors.

**NOTE:** The european lens units may come with a single filament bulb holder and single filament amber bulb already installed. These are not to be used. They should be removed and discarded.

## 5 Series

97 thru 00

**PART NUMBER:**

E39 PCLR or E39 PSMK

**PARTS LIST:**

- (1) - Left parking light lens/headlight cover assembly
- (1) - Right parking light lens/headlight cover assembly
- (2) - Amber dual filament bulbs

**PROCEDURE:**

1. Open the engine hood.
2. Remove the harness plugs from the high and low beam bulbs and remove the parking light bulb and socket assembly.
3. Remove the four 8mm hex head screws that secure the headlight assembly to the vehicle. Two are at the top of the assembly and two are just below the high and low beam bulbs at the rear. Pull the assembly toward the front and remove it. Repeat for the other side.
4. The lens cover is secured to the headlight bucket with six molded plastic clips. Two clips at the top, three clips at the bottom and one clip on the high beam side. The top clips have a melted seal; gently break the seal to release the top clips, then release the remaining clips. Remove the lens cover from the assembly.
5. Remove the painted lower trim piece by releasing the two snaps at the bottom and one snap at the high beam side.
6. Remove the two metal clips at the bottom of each glass lens which secure the lenses into the cover. Use a screwdriver to gently remove the glass lenses from the covers. Pay attention to which lens is for the high beam and which is for the low beam.
7. If the new lens covers do not have the small rubber vent tubes at the parking light housing, remove them from the originals and install them on the new covers.
8. Install the glass lenses into the new lens covers and replace the clips.

**NOTE:** If the new lens covers come with the glass lenses already in them, remove the lenses and replace them with your original lenses.

9. Install the painted trim strip to the new cover. Be sure the snaps are secure.
10. Install the new lens covers onto the headlight assembly. Be sure the snaps are secure.
11. Install the headlight assemblies into the vehicle. There is a hook on the lower painted trim strip, (at the parking light end) which hooks inside the corner of the fender.
12. Replace the four 8mm hex head screws and connect the wiring sockets to the high and low beam bulbs. Before installing the parking light socket and bulb, replace the clear bulb with the amber bulb, which is supplied with the kit.



Call Toll Free: **1.800.535.2002**