



BAVARIAN AUTOSPORT

Burlwood E-Brake Handle Installation Instructions

NOTE: In some instances, the original E-Brake handle will be damaged or destroyed in the process of removing it. If this is undesired, proceed with care and stop short of any process that would damage the handle. You are welcome to return the handle if this is the case.

3 Series

92 on

Z3

PART NUMBERS:

GSBE 3ER
GSBE 3BCH
GSBE 3CFCH
GSBE 3LCH

5 Series

89 on

7 Series

88 thru 94

PART NUMBERS:

GSBE 5ER
GSBE 5BCH
GSBE 5CFCH
GSBE 5LCH

PROCEDURE:

1. Release the emergency brake. Unscrew the release button and remove it.
2. The original E-Brake handle is to be pulled off. There are no locking tabs, screw threads or any other mechanical means of securing the handle to the lever. However, on the newer models, the fit is very tight and the handle may be glued on. If pulling and twisting on the handle will not remove it, the handle will have to be knocked off from behind using a wood block and a hammer or cut off.
3. Once the original handle is removed, clean up the lever and slide the new Bavarian Autosport handle onto the lever. Gently twist and pull the handle into position so that it is secure. If the new handle is not secure, add a small amount of silicone adhesive to the inside of the handle before installing. Replace the screw-on release button.

