



**BAVARIAN AUTOSPORT**

# Clear Parking Lights Installation Instructions

**SAFETY NOTE:** Be sure the ignition switch and light switch are in the **OFF** position before removing or attaching any electrical connectors.

**NOTE:** The clear European lens units may come with a single filament bulb holder and single filament amber bulb already installed. These are not to be used. They should be removed and discarded.

## 7 Series

95 thru 01

### PART NUMBERS:

E38 PCLR 98

E38 PCLR 99

### PARTS LIST:

(1) - Left clear parking light lens assembly

(1) - Right clear parking light lens assembly

(2) - Amber dual filament bulbs

### PROCEDURE:

1. Open the engine hood.
2. Remove the driver's side round access cover (about 4" diameter) from the plastic inner side panel directly behind the low beam headlight rear cover.
3. Remove the air filter box (behind the right side headlight) by loosening the hose clamp on the air inlet tube at the right side access hole, removing the 10mm mounting bolt located at the rear side of the box and then releasing the two clips securing the box to the Mass AirFlow (MAF) Sensor. Gently separate the box from the MAF... be careful not to damage or lose the large o-ring seal.
4. Remove the small plastic plug from the hole located on the top of the fender. The plug is black, about 1/2" in diameter, and is located about 6" rearward of the front edge of the fender.
5. Insert a long Phillips-head screwdriver into the hole. Using your free hand through the large access hole, locate the screwdriver into the round screw clamp. Loosen the screw and push the parking light housing forward with your other hand (through the access hole). Note the U-shaped horizontal tab at the rear of the housing, this is the securing tab.
6. Remove parking light bulb and socket assembly from the parking light housing. Remove the clear bulb from the bulb socket.
7. Remove the bulb socket and single filament amber bulb (if installed) from the new clear parking light housings and discard them.
8. Install the new dual filament amber bulbs (supplied with the kit) into the original bulb sockets.
9. Install the bulb sockets into the parking light assemblies.
10. Slide the parking light assemblies into place, being careful to align the vertical side alignment tabs with the corresponding receptacles on the sides of the headlight assemblies.
11. Using your hand through the access hole, assure that the horizontal U-shaped hold-down tab at the back of the parking light assembly is properly aligned with the screw clamp. Tighten the screw using the long Phillips-head screwdriver.
12. Replace the screw hole plugs, left access cover and the air filter box and inlet tube. (**NOTE:** Lubricate the MAF o-ring with oil, light grease or petroleum jelly before installing.)



Call Toll Free: **1.800.535.2002**