



BAVARIAN AUTOSPORT

# Floor Jacking Pad Installation Instructions

**SAFETY NOTE:** This jacking pad is intended to be used **ONLY** to lift the vehicle so that proper jack stands can be installed. Never work on or under the vehicle while it is supported by the floor jack and jacking pad.

**NOTE:** Never use more than one jacking pad at a time. Lift only one corner of the vehicle at a time.

## 3 Series

92 thru 98

### PARTS LIST:

JACK PAD

### PROCEDURE:

1. With vehicle on a flat and level surface, apply the park brake and properly chock the wheels. Keep in mind that if you are raising the rear of the car, the park brake will not be functional in holding the vehicle. Be sure to chock all wheels that will be on the ground.
2. Use a flat blade screwdriver to remove the jack port plug from the side skirt, by turning the plug counter-clockwise.
3. Insert the jacking pad with the round flat pad facing downward.

**IMPORTANT NOTE:** The jacking pad **MUST** be **FULLY** inserted into jacking port. There must be no part of the machined locator slots showing past the jacking port. Failure to observe this may result in a failure of the jacking pad, personal injury or damage to your BMW.

4. Roll the floor jack under the jacking pad. Center the floor jack's lifting pad under the jacking pad and pump the jack to raise it to meet the jacking pad.
5. Continue raising the vehicle watching to make certain that the jacking pad does not move out of the jacking port at all. If the pad moves out of the port, lower the jack and reposition the jacking pad and jack and try again. If you are on an un-level or rough surface that is preventing the floor jack from rolling as it is lifting, the jacking pad may have a tendency to pull out of the jacking port. **If this is happening, you must stop and adjust your jacking location.** Continuing to lift the vehicle with the jacking pad not fully inserted into the jacking port may lead to failure of the jacking pad.
6. Once the vehicle is lifted, properly place the jack stand and lower the floor jack.
7. Proceed to the other side, lift your BMW and then support with a jack stand (repeat steps 2 through 6).



Correct



Incorrect



Call Toll Free: **1.800.535.2002**