

**BAVARIAN AUTOSPORT**

# M-Tech Body Aerodynamic Kit Installation Notes

**NOTE:** These instructions will assume that the installer is familiar with the standard installation of this aerodynamic kit and has the BMW installation instructions.

## 3 Series 4 door

*02 on***PART NUMBER:**

51 71 0 139 650

**PROCEDURE:**

1. The new fog lights, which are included with this aero kit, may use a different bulb and bulb connector from the original ones on the car. Please make note that the original fog lights may use H-11 bulbs or 9006 bulbs. If the new fog light bulbs (installed in the new fog lights included with the kit) do not match the bulb connector plugs on the vehicle, please call us. We have the adapter plugs in stock (part number EHALL).
2. If your application requires the connector plugs to be changed, simply cut the existing fog light connector plugs from the wiring and install the supplied connector plugs using crimp connectors; or, you may wish to solder and heat shrink the splices.
3. The new fog lights (used with this kit) use 9006 bulbs. When replacing burned out bulbs be sure to ask for 9006 bulbs!

