



BAVARIAN AUTOSPORT

E39 Stressbar Installation Instructions

NOTE: These instructions will assume that the installer is familiar with the standard installation of a stressbar on a BMW. This Racing Dynamics stressbar has a unique installation, which is detailed in this instruction sheet.

5 Series

PART NUMBER:

6 cyl. 196 99 39 011
97 thru 03

PROCEDURE:

NOTE: Refer to Figure 1 for all steps.

1. Remove the mounting feet from the stressbar.
2. Install the passenger mounting foot to the passenger strut tower (this is the foot with the longer bar mounting plates), with the holes in the bar mounting plates facing outboard. . . toward the outside of the car.
3. Install the driver side mounting foot, with the holes in the bar mounting plates facing inboard. . . toward the inside of the car.
4. Install the bar between the passenger and driver side mounting feet.



Figure 1

BAVARIAN[®]
autosport

275 Constitution Avenue, Portsmouth, NH 03801

Call Toll Free: **1.800.535.2002**

• 603.427.2002 • Fax 800.507.2002 • www.BavAuto.com