

**BAVARIAN AUTOSPORT**

OBC Illumination Installation Instructions

SAFETY WARNING: Be sure the ignition switch and light switch are in the OFF position before removing or attaching any electrical connectors.

5 Series

89 thru 96

PART NUMBER:

OBC ILLUM E32/4

7 Series

88 thru 94

PROCEDURE:

1. Remove the radio by using the anti-theft radio removal tool (available from Bavarian Autosport). Open the small flap doors at the left and right edges of the radio face, insert the tool and loosen the screws (counter-clockwise). Pull the radio out. You do not specifically need to unplug the radio connections, but it does make the OBC removal easier since the radio will not be hanging in the way. You will need the radio anti-theft code to activate the radio, if the wiring harnesses are unplugged.
2. Notice the release lever, for the OBC, in the upper right corner through the radio opening. Slide the lever forward to release the OBC from the panel. Pull the OBC out.
3. Using needle-nose pliers, remove the burned-out bulbs for the display and key pad illumination and replace with the new ones.
4. Install the OBC and lock the release lever.
5. Install the radio and secure the anti-theft screws.

