

**BAVARIAN AUTOSPORT**

# PIAA Euro-Tone Sport Horn Installation Instructions

**INSTALLATION NOTE:** *These PIAA horns are intended as a universal installation. In other words, the mounting and wiring will not especially be the same as the existing horns on your BMW (or other vehicle). Since all BMW models differ a bit in the actual horn mounting, we will not address the detailed mounting of the horns. You should be able to mount the PIAA horns in a similar manner to the original horns. All BMWs will have the horns mounted in the general area behind the front bumper (most models have two horns, one high tone and one low tone). Most BMW models have one horn on the left side and one on the right side, behind the front bumper.*

## All BMWs

**PART NUMBER:**

85112

**PROCEDURE:**

1. Locate the original horns. You may have to remove the lower plastic splash panel, behind the bumper fascia, to access the horns.
2. Note how the horn is mounted to the vehicle. Take a look at the PIAA horn mounting bracket and determine your best method of mounting the new PIAA horn in place of the original BMW unit.
3. Unplug the electrical connectors from the original horn. Remove the mounting fasteners and remove the horn.
4. If the original BMW wiring does not have standard female spade connectors as the connector terminals for the wiring, you will need to replace the existing terminal connectors with the female spade connectors that we have included with the PIAA horns. Simply cut the existing connectors from the wires, strip the ends of the wires and crimp on the supplied female spade connectors, using the proper standard crimping pliers.
5. Install the horns and connect the wiring spade connectors. Polarity does not matter.

Call Toll Free: **1.800.535.2002**