



BAVARIAN AUTOSPORT

# Hamann Front Spoiler Installation Instructions

**IMPORTANT NOTE:** These instructions are translated from the original German instructions. Read these instructions fully before attempting installation. Spoiler must be test fit and adjusted prior to any painting.

**Z4** PART NUMBER:  
All 10044100

**PROCEDURE:**

1. Remove the outer screws securing the original front splash shield, behind the bumper.



2. Align and center the front spoiler to the front of the vehicle.



3. Hamann front spoiler mounts to the original mounting points for the under splash shield, using the original screws.



**BAVARIAN**<sup>®</sup>  
autosport

Call Toll Free: **1.800.535.2002**

275 Constitution Avenue, Portsmouth, NH 03801 • 603.427.2002 • Fax 800.507.2002 • [www.BavAuto.com](http://www.BavAuto.com)