



# Ultimate Rotors Installation Instructions

**IMPORTANT!!!** Brake rotors for M3 95 thru 99 are directional; they have angled cooling vanes between the two surfaces of each rotor. Our Ultimate rotors should be installed only in the direction indicated.

## M3

95 thru 99

Installed properly (Figure 1), our Ultimate rotors will provide smooth, progressive braking without any vibration or noise.

**NOTE:** Next to the curved slots on each rotor are small, countersunk holes (i.e. they do not go all the way through the rotor's surface). These are wear indicators. When the indicators are no longer visible, the rotor must be replaced.




Figure 1